

SCHWEGO® daily clean 5776

Aqueous cleaner for water-based flexo printing inks

Function SCHWEGO® daily clean 5776 is characterized by its high cleaning power and an environmentally friendly composition. The cleaner is very well suited for use in corrugated direct printing. Also in other sectors, e.g. B. Tissue, a thorough cleaning takes place.

Outstanding cleaning of anilox and chrome rollers, chamber doctor blades, ink pumps, clichés and flexo sleeves.

Properties

- Water miscible
- Aromatic-free
- Surfactants biodegradable
- Odorless
- Alusafe (dilution according instructions for use)
- ISEGA-certified
- FOGRA-certified (for Baldwin systems)



Application For normal soiling we recommend a dilution of SCHWEGO® daily clean 5776 with water at a ratio of 1:10. For stubborn dirt, please dilute 1:8. To clean the anilox rollers, pour SCHWEGO® daily clean 5776 into a bucket and let it circulate for 10-15 minutes, by using the circulation pump. Then rinse with water for 2-3 minutes.

Storage The described properties of SCHWEGO® daily clean 5776 remain constant for at least 12 months if stored properly.

Packaging 20 l canister | 200 l drum | 600 l container | 1000 l container

