

SCHWEGO® aqua gel 8481

Aqueous cleaning gel for anilox rollers

Function SCHWEGO® aqua gel 8481 is used to clean anilox rollers. Residues from

waterbased varnishes and printing inks are removed from the cells.

SCHWEGO® aqua gel 8481 convinced by its outstanding cleaning effect and the

economically advantageous consumption.

Properties

• Neutral smell

• Non-combustible

Tensides are biologically degradable

Low VOC

Certified by BG ETEM as "low emission product"

Application SCHWEGO® aqua gel 8481 is applied with a brush or rag on the anilox rollers. Let

react 5 – 10 minutes, after rinse with water. Repeat cleaning for heavily soiled

rollers. Rub dry the rollers after cleaning.

Storage Subject to appropriate storage, the described properties of SCHWEGO® aqua gel

8481 remain stable for at least 12 months.

Packaging 1 l bottle



